

**HER-SPEC FEATURE:**

# **SMOOTH ENGAGE & RELEASE**

---

Set blades to desired open position by pushing center tab to automatically lock blades in place. Easily release blades by pushing tabs located to the right or left of center tab. **Blades require tension to effectively release.**

